



Scheib Drainage  
Products

## 'No-Seep' Antiseep Collar

The collars can be built to fit any kind of pipe up to 48". The three basic sizes are 4' x 4', 5' x 5", and 6' x 6'. Collars are also available in 7' x 7' and 8' x 8'.

### Installation Instructions

1. Apply tar or mastic to collar and lay tube on collar.
2. Apply mastic to the top half of the collar and set in place.
3. Line up the red stripes and bolt the two halves together.
4. Install metal bands on split halves of collar.
5. Tighten bolts and bands.
6. Apply mastic as needed to insure a good seal.
7. Backfill and hand tamp.



- Typ. 18" - 24" from edge of pipe to edge of collar on all four sides

- Stainless steel bands on each side

- The 2 halves overlap 1.5" to allow the pieces to be bolted together

- 3/8" holes allow for adjustment of 1/4" stainless steel bolts (typ. spaced 6" apart)

- The two piece connecting band is made from 1/8" polyethylene and extends a minimum of 3" from the center on each side and is joined to the body with a continuous weld on both sides

- The 'No-Seep' Antiseep collar is constructed from durable 1/4' Polyethylene



[www.drainagesolutionsinc.com](http://www.drainagesolutionsinc.com)

(317)346-4110