


# OilTector<sup>®</sup>

**Quick Start**  
**1 Phase Simplex Auto-Valve**


# Liberty Pumps<sup>®</sup>

Use the (Installation Example) diagram **1** on the bottom right of this page as a reference to match up each component included in this system to the correct terminal blocks inside the control panel **A** shown in diagram **2**

Follow steps **3** through **11** on this page and in order. Note for step **8** on bottom.



Note: The pump **8** is wired to the bottom of the disconnect switch in the junction box **B** then the top of the disconnect switch in the junction box is wired to the control panel **A** Terminals T1 & T2.



# Liberty Pumps<sup>®</sup>


## QUICK START

**USE PAGE 2 FOR ROUND SHAPED HOLDING TANKS (Follow Steps A-0)**


**USE PAGE 3 FOR RECTANGLE OR SQUARE SHAPED HOLDING TANKS (Follow Steps A-0)**

### A. Turn On Power To The Control Panel


**B.** Press (Configure Oil Tank)




**C.** Press (Enter Pump GPM)




**D1.** Enter Pump Gallons Per Minute From Pump Nameplate.  
**D2.** Press ENT




**E1.** Press (Round Tank)  
**E2.** Press (Round Dimensions)




**F1.** Press (Diameter Inches) Button. **F2.** Enter Oil Tank Diameter. Press ENT. Repeat For Depth.




**G1.** Press (Back) Button On Round Tank Screen




**G2.** Press (Back) On Select Oil Storage Tank Screen



**G3.** Press (Next) On Today's Date Screen




**H.** Press (Maintenance Menu) Button




**I1.** Enter Password (1001) as shown below.


- I2. Press Arrow Keys Until 1 Is Highlighted
- I3. Press ENT (1st \* appears)
- I2. Press Arrow Keys Until 0 Is Highlighted
- I3. Press ENT (2nd \* appears)
- I2. Press Arrow Keys Until 0 Is Highlighted
- I3. Press ENT (3rd \* appears)
- I2. Press Arrow Keys Until 1 Is Highlighted
- I3. Press ENT (4th \* appears)
- I2. Press Arrow Keys Until OK Is Highlighted
- I3. Press ENT (You Will Be On Screen)




**J.** Press Pump / Valve To Verify Position Of Switches.  
Note: Off Delay Is Preset To 10 Seconds.



**N1.** Place All Switches In Auto  
**N2.** Press Home Button



**O.** Place Pump HOA'S into Auto Mode And Do The Bucket Test (See Page 20 Of Main Manual)



After completing step **O** you have finished the quick start and are on the Home Screen

- Back** Will Always Take You To The Previous Screen
- Home** Will Always Take You To The Home Screen

# OilTector<sup>®</sup>

## Quick Start

### 1 Phase Simplex Auto-Valve



## QUICK START - FOLLOW STEPS A-O IF USING A SQUARE OR RECTANGLE TANK

### A. Turn On Power To The Control Panel

**B. Press (Configure Oil Tank)**

**C. Press (Enter Pump GPM)**

**D. D1. Enter Pump Gallons Per Minute From Pump Nameplate. D2. Press ENT**

**E. E1. Press (Rectangle Tank) E2. Press (Rectangle Dimensions)**

**F. F1. Press (Length Inches) Button. F2. Enter Length. Press ENT. Repeat For Width & Depth.**

**G1. Press (Back) Button On Square/Rectangle Screen**

**G2. Press (Back) On Select Oil Storage Tank Screen**

**G3. Press (Next) On Today's Date Screen**

**H. Press (Maintenance Menu) Button**

**I. I1. Enter Password (1001) as shown below. I2. Press Arrow Keys Until 1 Is Highlighted I3. Press ENT (1st \* appears) I2. Press Arrow Keys Until 0 Is Highlighted I3. Press ENT (2nd \* appears) I2. Press Arrow Keys Until 0 Is Highlighted I3. Press ENT (3rd \* appears) I2. Press Arrow Keys Until 1 Is Highlighted I3. Press ENT (4th \* appears) I2. Press Arrow Keys Until OK Is Highlighted I3. Press ENT (You Will Be On Screen)**

**J. Press Pump / Valve To Verify Position Of Switches. Note: Off Delay Is Preset To 10 Seconds.**

**N. N1. Place All Switches In Auto N2. Press Home Button**

**O. Place Pump HOA'S into Auto Mode And Do The Bucket Test (See Main Manual)**

After completing step **O** you have finished the quick start and are on the Home Screen

**Back** Will Always Take You To The Previous Screen

**Home** Will Always Take You To The Home Screen