

C Cutter Instructions 03402, 03412, 03413, 03414

Snap the cutter onto the copper tubing in the location where cut is desired. Turn the spring-loaded tubing cutter in the direction of the arrows etched onto the tool. This permits the springs on the cutter wheel to tighten with each rotation around the pipe. Turn until cut is complete.

Replacement Cutter Wheel: #03376 TCKCW or 2-pack #63376 2PK-TCKCW

Each cutter fits just one size of tubing: 1/2", 3/4", or 1"





Reed Manufacturing 1425 West 8th Street Erie, PA 16502 USA Phone: 800-666-3691 or 814-452-3691 Fax: 800-456-1697 or 814-455-1697 www.reedmfgco.com

TCKINST-0320