

NOTE:

- MUST BE INSTALLED 10' AWAY FROM STRUCTURE OR FOUNDATION.
- FWAS24 KIT DOES NOT COME WITH FWPB24 BTM.
- REFERENCE FLO-WELL CALCULATOR ON NDSPRO.COM


NDS FLO-WELL^M GRAVEL INSTALLATION.

NON LOAD BEARING INSTALLATION. OPTIONAL SURFACE PORT CONFIGURATION.



(317) 346-4110 www.drainagesolutionsinc.com





NOTE:

- MUST BE INSTALLED 10' AWAY FROM STRUCTURE OR FOUNDATION.
- FWAS24 KIT <u>DOES NOT</u> COME WITH FWPB24 BTM.
- REFERENCE FLO-WELL CALCULATOR ON NDSPRO.COM


NDS FLO-WELL^m SAND INSTALLATION.

NON LOAD BEARING INSTALLATION.



(317) 346-4110 www.drainagesolutionsinc.com





NOTE:

- MUST BE INSTALLED 10' AWAY FROM STRUCTURE OR FOUNDATION.
- FWAS24 KIT <u>DOES NOT</u> COME WITH FWPB24 BTM.
- REFERENCE FLO-WELL CALCULATOR ON NDSPRO.COM


NDS FLO-WELL^M GRAVEL INSTALLATION.

NON LOAD BEARING INSTALLATION.



(317) 346-4110 www.drainagesolutionsinc.com







(317) 346-4110 www.drainagesolutionsinc.com



NOTE:

- MUST BE INSTALLED 10' AWAY FROM STRUCTURE OR FOUNDATION.
- FWAS24 KIT DOES NOT COME WITH FWPB24 BTM.
- REFERENCE FLO-WELL CALCULATOR ON NDSPRO.COM

$\underline{\text{NDS FLO-WELL}}^{\mathbb{M}} \operatorname{GRAVEL} \operatorname{INSTALLATION}.$

NON LOAD BEARING INSTALLATION LATERAL CONNECTION .

