

Anti-Seep Collars

Keep your pipe from being washed out.

- ◆ The Anti-Seep Collar works with any smoothwall pipe or corrugated plastic tubing.
- ◆ 1/16" gum rubber.
- ◆ Easy to install.
- ◆ Tan floating stock has superior resilience, elongation, and tear strength.
- ◆ Resistant to water, most salts, mild acids, and many other chemicals.
- ◆ Wood frame.
- ◆ Economical to buy.

Anti-Seep Flanges—
1/16" Gum Rubber
with Wood Frame

ASC02	2' x 2'
ASC03	3' x 3'
ASC04	4' x 4'
ASC05	5' x 5'
ASC06	6' x 6'



Recommended Anti-Seep Collar

Pipe Size	Item#
3"	ASC02
4", 5", 6", 8", 10", 12"	ASC03
15", 18", 24"	ASC04
30", 36"	ASC05
42", 48", 60"	ASC06

Directions for Using The Anti-Seep Collar

1. Unroll the Anti-Seep Collar and align the boards to form a square. Attach metal brackets to the corner of the boards with the screws provided. Attach the rubber to the frame with the nails provided.
2. ***IMPORTANT—Cut a round hole** in the center of the rubber that is smaller than the pipe size (approx. 33% smaller). This will allow the rubber to stretch over the pipe when the Anti-Seep Collar is installed on the pipe. This will provide a tight seal between the pipe and the Anti-Seep Collar.

***Cutting an "X" or slit will cause the rubber to tear.**
3. Slip the pipe through the Anti-Seep Collar, inspect the seal between the pipe and the Anti-Seep Collar, carefully backfill, and compact with suitable soil.

CAUTION: Excessive compaction or downward pressure on wooden frame will cause rubber to stretch and distort resulting in loss of seal between rubber and pipe.

